

User Guide  
6622-2211



# DR-250



**DSL2/2+  
Router**

[www.westermo.com](http://www.westermo.com)

## **Legal information**

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy and reliability or contents of this document. Westermo reserves the right to revise this document or withdraw it at any time without prior notice.

Under no circumstances shall Westermo be responsible for any loss of data or income or any special, incidental, and consequential or indirect damages howsoever caused.

More information about Westermo can be found at the following Internet address:

**<http://www.westermo.com>**

## Safety



### **Before using this unit:**

Read this manual completely and gather all information on the unit. Make sure that you understand it fully. Check that your application does not exceed the safe operating specifications for this unit.

Hazardous voltages may occur within this unit when connected to a power supply. Prevent access to hazardous voltages by disconnecting the unit from its power supply.

Prevent damage to internal electronics from electrostatic discharges (ESD) by discharging your body to a grounding point (e.g. use of wrist strap).



### **Before installation:**

This unit should only be installed by qualified personnel.

This unit should be built-in to an apparatus cabinet, or similar, where access is restricted to service personnel only.

The power supply wiring must be sufficiently fused, and if necessary it must be possible to disconnect manually from the power supply. Ensure compliance to national installation regulations.

This unit uses convection cooling. To avoid obstructing the airflow around the unit, follow the spacing recommendations (see Installation section).

## Care recommendations

Follow the care recommendations below to maintain full operation of unit and to fulfil the warranty obligations.

This unit must not be operated with covers or lids removed.

Do not attempt to disassemble the unit. There are no user serviceable parts inside.

Do not drop, knock or shake the unit, rough handling beyond the specification may cause damage to internal circuit boards.

Do not use harsh chemicals, cleaning solvents or strong detergents to clean the unit.

Do not paint the unit. Paint can clog the unit and prevent proper operation.

Do not expose the unit to any kind of liquids (rain, beverages, etc). The unit is not waterproof.-Keep the unit within the specified humidity levels.

Do not use or store the unit in dusty, dirty areas, connectors as well as other mechanical part may be damaged.

If the unit is not working properly, contact the place of purchase, nearest Westermo distributor office or Westermo Tech support.

## GSM specific safety

Please read and follow the guidelines listed below. The precautions must be observed during all phases of the operation. Breaking these rules may be dangerous, illegal or affect performance of the unit and/or invalidate the unit's approval and/or warranty.

## **General**

Remember to follow any special regulations and warnings in force in any area and never use the unit whenever it's forbidden to use it. Do not use the unit when it may cause interference or danger. A wireless device exposed to interference above specified limits could result in deteriorated performance.

## **Hospitals or other Medical environment**

Do not use the unit in a medical environment such as health care facilities. Follow any regulations or rules that instruct you to not use the unit.

### *Pacemakers*

The Health Industry Manufacturers Association recommends that a minimum separation of six (6") inches be maintained between cellular wireless equipment and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- ⚡ Should ALWAYS keep the the unit and its antenna more than six inches from their pacemaker when the unit is turned ON.
- ⚡ If you have any reason to suspect that interference is taking place, turn your wireless equipment OFF immediately.

### *Hearing Aids*

Some digital wireless equipment may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider [or call the customer service line to discuss alternatives.]

### *Other Medical Devices*

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy.-Your physician may be able to assist you in obtaining this information.

Turn the wireless equipment OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

## **Aircraft**

Do not use the unit in an aircraft. The use of a wireless unit in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless network, and may be illegal.

Failure to observe these instructions may lead to suspension or denial of cellular services to the offender, legal action, or both.

## **Vehicle**

If the unit is incorrectly installed in a vehicular environment, the operation of the unit could interfere with the vehicle electronics. Faulty installation and/or operation can constitute a safety hazard.

### **For Vehicles equipped with an airbag**

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

### **Blasting areas**

Do not use the unit where blasting is in progress or in “blasting areas”. Observe restrictions and follow any regulation or rules.

### **Explosive atmospheres**

Do not use the unit in any area with a potentially explosive atmosphere.

Potentially explosive areas are often, but not always, clearly marked.

They include fuelling areas such as petrol stations, below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powder.

### **RF energy**

The MR-200 is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from the wireless unit. All radio-transmitting devices send signals, which may cause interference in different electronic devices. To avoid interference, place the unit's antenna a sufficiently long distance from other electronics.

### **Critical applications**

Cellular units operate using radio signals and cellular networks cannot be guaranteed to connect in all conditions. Therefore you should never rely solely on a wireless device for essential communications, for example medical emergencies.

### **Backup copies**

Remember to make backup copies of all important data, for example PIN/PUK codes, contents of SIM card etc.

### **Antenna care**

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the unit and may violate current regulations.

Do not touch the antenna unnecessarily when the unit is in use. Contact with the antenna affects call quality and may cause the unit to operate at a higher power level than otherwise needed.

### **Maintenance**

No maintenance is required, as long as the unit is used as intended within the specified conditions.

## Agency approvals and standards compliance

Type	Approval / Compliance
EMC	EN301489-07: v1.2.1 (2002-08) EN55022 1998 EN55024: 1998+A1:2001
Safety	IEC60950-1: 2005 Second Edition EN60950-1:2006
RF spectrum	EN301511: v9.0.2

# Declaration of Conformity



Westermo Teleindustri AB

## Declaration of conformity

The manufacturer Westermo Teleindustri AB  
SE-640 40 Stora Sundby, Sweden

Herewith declares that the product(s)

Type of product	Model	Art no	Installation manual
Table top	DR-250	3622-0010	6622-2211
DIN-rail			

is in conformity with the following EC directive(s).

No	Short name
89/336/EEG	Electromagnetic Compatibility (EMC)
73/23/EEG	Low Voltage Directive - LVD
1999/5/EC	RTTE Radio and Telecommunications Terminal Equipment

References of standards applied for this EC declaration of conformity.

No	Title	Issue
EN 55024	Information technology equipment - Immunity characteristics	1998 + A1:2001
EN 55022	Information technology equipment - Radio disturbance characteristics	1998
EN 60950-1	Safety of information technology equipment	A11 (2004)

The last two digits of the year in which the CE marking was affixed: 08

Hans Levin  
Technical Manager  
27th February 2008

Postadress/Postal address  
S-640 40 Stora Sundby  
Sweden

Tel.  
016-428000  
Int+46 16428000

Telefax  
016-428001  
Int+46 16428001

Postgiro  
52 72 79-4

Bankgiro  
5671-5550

Org.nr/  
Corp. identity number  
556361-2604

Registered office  
Eskilstuna

## Type tests and environmental conditions

<b>Environmental</b>		
Temperature	Operating	-20 to +55°C
<b>Packaging</b>		
Enclosure	Pressed steel	
Dimension W x H x D	236 x 146 x 29 mm	
Weight	0.8 kg – 1.1 kg dependant on model and options installed	
Mounting	Horizontal on 35 mm DIN-rail or flat on level surface	

## Description

The DR-250 is based on the very latest ADSL2/2+ platform, supporting the fastest broadband speeds available. ADSL2 offers considerable performance benefits over standard ADSL, including improved range and data rate.

The DR-250 has an integral four port Ethernet switch and a 25 pin RS-232 serial interface for local connectivity. Devices that support serial protocols such as Modbus RTU, DF1, DNP3, IEC870 etc can be easily connected to the DR-250 via the serial port.

The Ethernet interfaces support Multicasting (IGMP), VLAN, SNMP, SNTP, FTP, as well as all the standard TCP, UDP and DHCP protocols. The inbuilt RS-232 port can be used to connect legacy serial based equipment such as PLC's, RTU's or IED's. Alternatively the internal serial port can be used as a backup connection to the remote site when used in conjunction with a suitable Westermo Modem.

The DR-250 router has an integrated stateful inspection firewall and can support 20 IPSEC VPN (Virtual Private Network) terminations which can be secured using standard DES, 3DES, AES encryption and MD5 or SHA1 key exchange protocols. These features ensure that the remote sites can use the latest security technology to resist denial of service and hacking attacks. The VPN's can be used as a way of increasing security and to create secure tunnels, running between sites. The VPN's can be used to interconnect sites effectively replacing the requirement for dedicated leased lines. A VPN tunnel can be established between any of the DR or MR series routers. Alternatively VPN's can be created between the DR-250 and a third party router. An optional license for 50 or 100 VPN terminations is also available (up to a maximum of 200).

The DR-250 can also be used for remote sites access, allowing the user to browse WEB pages, monitor / edit PLCs or access any device connected to the LAN. The DR-250 will allow devices on the LAN to send emails or connect to FTP servers.

Multiple routers can be used on the same LAN to provide redundancy. The routers use VRRP (Virtual Redundant Router Protocol) to allow a seamless changeover between primary and backup routers. For complex mesh network applications the DR-250 supports OSPF, BGP and RIP2.

The DR-250 can be supplied with a combination of UMTS 3G/HSDPA wireless card, and or PSTN/ISDN to backup the primary ADSL should there be an interruption in service.

The wide temperature range, 10 – 28 VDC supply and DIN rail mounting ensure that the DR-250 can be used in industrial applications without the need for modification or consideration of the environmental conditions.

### Features:

- ⌘ ADSL / ADSL2 / ADSL2+ Compatibility
- ⌘ Four port switch
- ⌘ Integrated RS-232 terminal server port
- ⌘ SNMP Management protocol
- ⌘ Firewall
- ⌘ IPsec VPN support (20 tunnels)
- ⌘ VRRP+, BGP, OSPF, RIP2, GRE, L2TP routing protocols
- ⌘ DIN Rail, wall or shelf mounted
- ⌘ –20°C to +55°C
- ⌘ 10 – 28 VDC supply
- ⌘ DES • 3DES • AES • SSL • SSH (standard)

## Interface specifications

<b>Power</b>	
Rated voltage	10 – 28 VDC
Rated current	1500 mA @ 12 VDC
Rated frequency	DC

<b>RS-232</b>	
Electrical specification	RS-232 V.24
Data rate	300 bit/s – 115.2 kbit/s
Data format	7 or 8 data bits, Odd, even or no parity, 1 or 2 stop bits
Transmission range	2 m
Connection	25-pin D-sub female (DCE)

<b>Ethernet</b>	
Electrical specification	IEEE std 802.3. 2000 Edition
Data rate	10 Mbit/s or 100 Mbit/s, auto-negotiated
Protocol	UDP, TCP, ICMP, HTTP and ARP
Duplex	Full- or half duplex, auto-negotiated
Circuit type	TNV-1
Transmission range	100 m
Connection	RJ-45 shielded, auto MDI/MDI-X


<b>Antenna (option)</b>	
Frequency bands	GSM1800 TX 1710 – 1785 and RX 1805 – 1880 MHz UMTS2100 TX 1920 – 1980 RX 2110 - 2170
Data rate	CSD: up to 14.4 kbit/s GPRS: up to 85.6 kbit/s
Connection	SMA female, impedance: 50 ohm

<b>SIM (option)</b>	
Electrical specification	3 volts SIM supported

# Connections

## SIM Card Sockets

The two sockets at the left side of the front panel are for the GSM SIM card(s) that you will receive from your service providers. Details of how to insert these correctly are given on page 13.



\* The USB host connectors may be used to connect compatible USB 2.0 client devices such as memory sticks, serial adapters, etc. Note that the total current available to power USB devices is collectively 0.5A (i.e. for both ports).

Cable	Description
Black	-VDC
Red	+VDC

\*\* RS-232 D-sub

25-position	Direction	Description
No. 2	In	Transmit Data (TD)
No. 3	Out	Receive Data (RD)
No. 4	In	Request To Send (RTS )
No. 5	Out	Clear To Send (CTS)
No. 6	Out	Data Set Ready (DSR)
No. 7	-	Signal ground (SG)
No. 8	Out	Data Carrier Detect (DCD) )
No. 15	In	Transmitter Clock (TxC)
No. 17	Out	Receiver Clock (RxC)
No. 20	In	Data Terminal Ready (DTR)
No. 24	In	External Transmitter Clock (ETC)

## LED Indicators

LED	Status	Description
PWR	ON	In service
	OFF	Out of service
LAN 0,1,2,3	ON	Network connection on LAN port
	OFF	No connection on LAN port
	Flash	Transmit or receive data on LAN port
DTE	ON	Terminal connected to the serial port and the DTR signal is on
	OFF	No connection on serial port Data is transmitted or received on the serial port
	Flash	Data is transmitted or received on the serial port
DSL	ON RED	No DSL is detected
	FLASH RED	DSL training
	ON GREEN	DSL active
	FLASH GREEN	Data being transferred
W-WAN	NET ON	A wireless network has been detected
	OFF	No wireless network has been detected
	SIM ON	A valid SIM card is installed in the unit
	OFF	No valid SIM card is installed in the unit
	DAT Flash	Data is being transferred over the wireless network
	OFF	No data is being transferred over the wireless network
Signal	The three indicators labelled SIGNAL illuminate to indicate the GSM signal strength as follows:	
	None illuminated	< -113 dBm (effectively no signal)
	1 LED illuminated	>= -112 dBm and <= -87 dBm (weak)
	2 LED's illuminated	>= -86 dBm and <= -71 dBm (medium)
	3 LED's illuminated	>= -70 dBm and <= -51 dBm (strong)
ISDN	D ON	Connected to ISDN network and D-channel active
	B1 ON	ISDN B-channel 1 active
	FLASH	Data being transferred
	2 ON	ISDN B-channel 2 active
	FLASH	Data being transferred
PSTN	OH ON	Modem off-hook
	CD ON	Connected to a remote modem
	DAT FLASH	Data being transferred

### Reset switch

This is located on the underside of the unit near the front. Pressing the switch gently with the tip of a pen or other suitable implement will generate a hardware reset.

Refer to page 15 (restoring factory defaults)

It is important to allow the DR-250 to complete the restore procedure. DO NOT press the reset button again or power cycle the unit for at least 2 minutes.

# Installation

## Mounting / Removal

The router should be positioned on a smooth, level surface making sure that there is adequate ventilation. Do not expose the router to extremes of heat or cold, strong magnetic fields or liquids.

If the GSM option is fitted it is important to remember that these products are wireless devices just like a mobile phone, so they will only operate reliably over the GSM network if there is a good signal.


For many applications the stub aerial provided will be suitable but in some circumstances it may be necessary to use a window-mounted or magnetically mounted aerial with an extended cable to allow the aerial itself to be positioned to provide the best possible signal reception. Westermo can supply a range of suitable aerials.

### Step 1 – Installing the SIM card(s) (wireless option)

The router incorporates two separate SIM card holders so that if your application demands it, you may install SIM cards for two different networks. This means that one wireless service may be used as a back-up service in the event that the primary service fails in some way. By default, SIM 1 is the default SIM used for access to the primary network and SIM 2 is used for the back-up network.

**Note:** SIM 1 and SIM 2 cannot be used to access two networks simultaneously.

The SIM card(s) should be inserted into SIM cardholders on the right of the front panel as illustrated below.



In both cases, the end of the SIM card with the chamfered corner should be inserted first. For SIM 1 the contacts should be face down. For SIM 2 the contacts should be face up.

The easiest way to get started is to use SIM-cards without PIN-code. If the PIN-code is activated it is possible to set this up in the settings for the router.

### Step 2 – Fitting the wireless antenna (if applicable)

The router is supplied with a “stub” antenna suitable for with the model you have ordered. Alternatively you may have ordered a different type of antenna separately. In either case this should be screwed onto the SMA aerial connector on the rear of the unit.

### Step 3 – Connecting the LAN cable

Plug one end of one of the supplied 2 metre CAT5 STP cable into the RJ45 socket labelled LAN 0. Plug the other end into the LAN socket on your PC or notebook.

#### **Step 4 – Connecting the serial cable**

For connection to a serial terminal device, connect the 25-way D plug on the serial cable provided to the SERIAL connector on the rear of the unit. Connect the other end of the cable (9-way D socket) to the terminal. If the serial connector on the terminal is not a 9-way D plug, you will need a suitable adapter.

#### **Step 5 – Connecting the ADSL cable**

Plug one end of the supplied cable, or a suitable alternative, into the RJ12 socket labelled ADSL. Plug the other end into the ADSL line socket.

#### **Step 6 – Connecting to the ISDN line (if applicable)**

Plug one end the supplied CAT5 cable into the RJ45 socket labelled ISDN. Plug the other end into the ISDN service outlet.

#### **Step 7 – Connecting to the PSTN line (if applicable)**

Plug one end of the supplied PSTN cable into the RJ45 socket labelled PSTN. Plug the other end into the PSTN wall socket.

#### **Step 8 – Connecting the power supply**

Plug the jack plug on the mains adapter into the socket labelled 12VDC. When power is first applied, the ON indicator will illuminate and the unit will initiate a series of diagnostic self-tests. During this process one or more of the other indicators, will flash to show that the unit is busy. When the flashing stops, the unit is ready to use.

The unit is now ready to be configured.

## Getting started

### IP Address

The default IP address of the DR-250 when delivered is 192.168.0.99.

### IP address configuration

The IP address is configurable by the Web tool and/or by using a terminal program. Below is a description of how to configure the IP address by using a terminal program.

1. If the address is known, connect to the unit from a Web browser with the address of the DR-250. If the address is unknown, connect the serial RS-232 interface to a terminal program with settings:  
Data rate: 115.2 bit/s  
Data bits: 8  
Stop bits: 1  
Parity: None  
Flow control: None
2. Use any terminal-program to setup the IP-address, gateway and subnetmask.  
Eth 0 ipaddr xxx.xxx.xxx.xxx (set up IP-address)  
Eth 0 gateway yyy.yyy.yyy.yyy (set up Gateway)  
Eth 0 mask zzz.zzz.zzz.zzz (set up subnetmask)  
Eth 0 status (check settings)  
Config 0 save (save configuration)
3. The unit is now ready for a complete configuration by the Web tool. Address DR-250 in a browser with the configured IP address. Note that the used computer have to be on the same network as DR-250.

### Username and Password for configuration

The DR-250 is username and password protected. These are used when connecting with Web browser during configuration and with Telnet for diagnostics.

Default username: username

Default password: password

### Restore Factory default settings

**Note!** This will clear your customized settings.

The factory default settings can be restored using the reset switch on the bottom of the unit. Pressing (~15 sec) the switch gently with the tip of a pen or other suitable implement will generate a hardware reset.

**Note!** If the default address of the unit is valid on the connected network it is possible to access the unit directly from a browser.

It is important to allow the DR-250 to complete the restore procedure. DO NOT press the reset button again or power cycle the unit for at least 2 minutes.

## Configuration by Web Tool

The DR-250 includes an easy-to-use Web configuration tool. The Web tool is very intuitive and includes useful help information for the configurable parameters.

Connect and login to the DR-250 on the default IP address and with default username and password combination (or your customized if configured) using a standard Web browser.

## Basic ADSL setup

The following must be done to get basic ADSL connectivity. There are two different ways that are used to get a ADSL connection. This depends on what your ADSL provider uses.

### PPP over Ethernet or PPP over ATM (PPPoE, PPPoA)

Username and password is supplied by your ADSL provider.

#### *ADSL Interface*

Choose the correct encapsulation PPPoE or PPPoA

#### *PPP Account*

Username: Supplied by your ADSL operator

Password: Supplied by your ADSL operator

Press Save then press OK

Press Reboot then press Reboot

After the reboot the Router will connect over ADSL and the LED DSL should flash green.

## Bridged Ethernet

#### *ADSL Interface*

Set **Encapsulation method** to **Bridged Ethernet VC-Mux** or **Bridged Ethernet LLC**.

(Check service provide details for correct setting)

Set **VPI** and **VCI** to match the values supplied by the ADSL service provide.

- **ETH4 Bridged ADSL**

Set **DHCP client** to **Enabled**

Set **NAT Mode** to **NAT**

- **Default route 0**

Set **Interface** to **Ethernet**

Set **Interface #:** to **4**

The **Source Mask** (255.255.255.0) should be removed

Press Save then press OK

Press Reboot then press Reboot

After the reboot the Router will connect over ADSL and the LED DSL should flash green.

## Basic Ethernet configuration

### **Basic IP Address**

- **Static IP**

To change the default IP-address 192.168.0.99 and subnet mask to something else.

### **Basic IP Address**

- **DHCP**

Minimum assigned IP address: eg 192.168.0.2

IP address range: eg 20 (highest address will then be 192.168.0.22)

DNS server address: Address of router (192.168.0.99 default setting)

Gateway address: Address of router (192.168.0.99 default setting)

Mask: 255.255.255.0

All settings above must be saved to one of the two profiles and then restarted.

After that change the IP-address of the client computer to accept an IP-address from the DHCP server in the DR-250 and verify that the computer receive a correct IP-address.

### **Time**

To setup the internal clock of the router to get correct time in logs etc.







Westermo Teleindustri AB • SE-640 40 Stora Sundby, Sweden

Phone +46 16 42 80 00 Fax +46 16 42 80 01

E-mail: [info@westermo.se](mailto:info@westermo.se)

**Westermo Web site: [www.westermo.com](http://www.westermo.com)**

---

### Subsidiaries

---

#### Westermo Data Communications AB

Svalgången 1

SE-724 81 Västerås

Phone: +46 (0)16 42 80 00 • Fax: +46 (0)21 35 18 50

[info.sverige@westermo.se](mailto:info.sverige@westermo.se)

#### Westermo OnTime AS

Gladsvei 20 0489 Oslo, Norway

Phone +47 22 09 03 03 • Fax +47 22 09 03 10

E-mail: [contact@ontimenet.com](mailto:contact@ontimenet.com)

#### Westermo Data Communications Ltd

Talisman Business Centre • Duncan Road

Park Gate, Southampton • SO31 7GA

Phone: +44(0)1489 580-585 • Fax: +44(0)1489 580586

E-Mail: [sales@westermo.co.uk](mailto:sales@westermo.co.uk)

#### Westermo Data Communications GmbH

Goethestraße 67, 68753 Waghäusel

Tel.: +49(0)7254-95400-0 • Fax: +49(0)7254-95400-9

E-Mail: [info@westermo.de](mailto:info@westermo.de)

#### Westermo Data Communications S.A.R.L.

9 Chemin de Chilly 91160 CHAMPLAN

Tél : +33 1 69 10 21 00 • Fax : +33 1 69 10 21 01

E-mail : [infos@westermo.fr](mailto:infos@westermo.fr)

#### Westermo Data Communications Pte Ltd

2 Soon Wing Road #08-05

Soon Wing Industrial Building

Singapore 347893

Phone +65 6743 9801 • Fax +65 6745 0670

E-mail: [earnestphua@westermo.com.sg](mailto:earnestphua@westermo.com.sg)

*Westermo Teleindustri AB have distributors in several countries, contact us for further information.*